

***Prior to installation of the underlayment, follow the flooring manufacturer's recommendations and/or instructions concerning site conditions and installation.**




Step 1:

Make sure the subfloor is structurally sound, level and is free of dust and debris. The deflection cannot exceed $L/360$ of the span under intended live and dead loads. Check for protruding nails and/or defects in the subfloor. If installing over concrete, the concrete must be dry with moisture emission rates that do not exceed 3lbs. per 1000 square feet per 24 hours as measured by the Anhydrous Calcium Chloride Test.




Step 2:

Start in a corner and begin installing the FloorMuffler® LVT parallel to the wall in the opposite direction as you plan to install the flooring planks. When installing the FloorMuffler LVT, leave at least 2" going up the wall.



Step 3:

Roll out the next roll of FloorMuffler® LVT in the same manner making sure that the foam seams are butted together.



Step 4:

If installing the FloorMuffler® LVT on concrete or below grade subfloors, be sure to tape the seams together with 2" tape that meets the moisture vapor transmission rate for this type of installation.



Step 5:

Install the flooring per the flooring manufacturer's instructions.